

# How to connect ziipos with Zeller


This works with **WINDOWS SERVER ONLY**

Before we start, please ask the customer : "Can you see POS mode icon on top-right of the screen?"


if yes, we can keep going, otherwise, the customer must call zeller to get their terminal updated with intergration mode

## Step 1:

Download Linkly for Zeller from <https://www.linkly.com.au/resources-support/software>



[Our Solutions ▾](#) [Resources & Support ▾](#) [About Us ▾](#) [Contact Us](#)

[HELP DESK](#) | [PAY NOW](#) | [SIGN UP](#) | [LOG IN](#) | 

---

## Official Releases

Installers, tools and code samples for use when developing a new integration and adding new features to existing integrations:

### In-store software v5.6.8 - standard install

Download and install the latest Linkly software to connect your Point of Sale software to your terminal. This installation option supports ANZ, Commonwealth Bank, NAB, Westpac, Suncorp and Fiserv terminals. Click [here](#) for release notes.

[New Installs](#) [Existing Installs & Upgrades](#)

### In-store software v5.6.9 - simple install (for Zeller terminals only)

Download and install the latest Linkly software to connect your Point of Sale software to your terminal. This installation option only supports Zeller terminals.

[Download](#)

### Specialty Terminal Drivers

For most terminals the correct drivers are included in the Linkly official release, however some terminals require special drivers to function correctly.

[CBA Albert](#) [CBA POS Ready](#)

### Pay@Table V3.1.0.0

The Pay at Table feature provides food and beverage businesses the flexibility to recall table orders and accept payments on the terminal at the customer's table.

[Download Software](#) [Download Demo](#)

[https://linklydownloads.z8.web.core.windows.net/installer/5.6.9/Zeller\\_LinklySetup.exe](https://linklydownloads.z8.web.core.windows.net/installer/5.6.9/Zeller_LinklySetup.exe)

## Linkly Configuration

1. Download the Zeller - Linkly software via <https://zeller.link/linkly-software>
2. Install the Linkly software onto your Mini PC
3. Restart the POS terminal once the download is complete.

You may now contact your POS provider to complete the required configuration on their end. Once this is complete, you can move ahead with configuring your Zeller Terminal.

Please note: Zeller Terminal configuration cannot be completed prior to contacting your POS provider.

## Zeller Terminal Configuration


Hibernate and sleep settings can interfere with the POS communicating with your Zeller Terminal and will need to be disabled. To do so:

1. Tap **Settings** from the navigation menu.
2. Select **Screen Settings > Device Hibernate**.
3. Toggle on **Never when plugged in**.
4. Toggle off **Device Hibernate**.
5. Press the back arrow and tap **Sleep mode**.
6. Toggle on **sleep mode** and set the inactivity timer to **1 hour**.

Before you complete the following steps, please ensure your Zeller Terminal is connected to the same WiFi network as your POS terminal.

### Step 2:

In ZiiPOS app, got to ipad setting



- Setting -> EFTPOS

Server IP  
192.168.185-8082 ↻ Auto Connect

Machine ID: POS1 System Language: English

Customer Display ID: Menu Item Description: Description2

Printer: None EFTPOS: Linkly[Connected ip:192.168.1.104] ↕

Sign out when device is locked: ☐ Receive message: ☒

Cash Machine IP Address: ☐

OK

Switch store

- -> EFT-Client Address: **Local Server IP should be 192.168.xxx.210**
- -> Port: **2011**
- Click **Connect** button

if the status changes to the "Connect", then pair completed



## Maintenance

Connect to the eftpos service:

POS ID:

POS2

EFT-Client Address:

Server IP

Port:

2012

☐ TEST MODEStatus: **CONNECTED**[Connect](#)[vConsole](#)

Revision #7

Created 15 September 2022 10:39:27 by Nan Li

Updated 28 April 2023 02:00:35 by Nan Li